

TRUCK, AIR DEFENCE, LAND ROVER 6 X 6, FFR, W/WINCH, FIRE UNIT VEHICLE (FUV)

LIGHT GRADE REPAIR

This instruction is authorised for use by command of the Chief of Army. It provides direction, mandatory controls and procedures for the operation, maintenance and support of equipment. Personnel are to carry out any action required by this instruction in accordance with EMEI General A 001.

Introduction

1. This EMEI contains procedures for removing, dismantling, repairing, assembling and installing various components of the Truck, Air Defence, Land Rover 6 x 6, FFR, W/Winch, Fire Unit Vehicle (FUV), shown in Figure 1. Where applicable, instructions for the adjustment, lubrication and minor servicing of these items are included. This EMEI should be read in conjunction with EMEI Vehicle G 203.




Figure 1 Truck, Air Defence, Land Rover 6 x 6, FFR, W/Winch, Fire Unit Vehicle (FUV)

CAUTION

Do not use adhesive tapes to seal fuel or oil openings. The adhesive tape is soluble in fuel or oil and can cause contamination. Remove temporary covers before assembling.

2. Prevent dirt and foreign objects from entering any component by placing clear temporary coverings over all exposed openings, including hoses, tubes and lines.

CAUTION

Before removing any electrical system components, disconnect the battery leads.

3. When disconnecting electrical connectors, hoses and fittings, remove clamps as required to gain slack and avoid damage to connectors and fittings.

4. Discard all used gaskets, seals, cotter pins, tab washers, lock pins, key washers, and lock washers. Discard all contaminated fuel and lubricants drained from the vehicle.

5. Use only those fuels and lubricants specified in the Servicing Instruction, EMEI Vehicle G 289, and the User Handbook when replenishing fuel or lubricants.

6. Any fastenings or fittings being tightened to prescribed torques are to have dry, clean threads unless otherwise specified. When specified, thread sealants are to be applied to dry, clean, oil-free threads.
7. The engine cooling system contains Nalcool Maximum corrosion inhibitor at a concentration of 12% total volume.
8. This vehicle is painted in polyurethane paint.

WARNING

Precautions should be taken prior to carrying out repairs which include painting, sanding, scraping or welding. For safety precautions refer to Introduction into Service Instruction, Materiel Management Policy Statement, Painting Policy for Vehicles and Equipment or relevant EMEL.

ENGINE - GROUP 1

Jockey Pulley

9. Removal:
 - a. Slacken the adjusting bolt on the jockey pulley arm (Figure 2), then rotate the pulley away from the fanbelts.
 - b. Remove the adjusting bolt from the pulley arm and mounting, then remove the pulley arm and pulley from the engine.
10. Disassembly:
 - a. Remove the grease nipple from the pulley bolt, then secure the pulley arm in a vice. Using a suitable spanner, remove the lock nut securing the pulley bolt, then remove the pulley bolt and pulley. Discard the lock nut.
 - b. Using circlip pliers, remove the internal circlip retaining the bearing in the pulley.
 - c. Remove the bearing from the pulley using a suitable drift or press.
 - d. Degrease the pulley in a suitable cleaning agent.
11. Reassembly:
 - a. Install the bearing, chamfered face first, into the pulley using a suitable drift or press.
 - b. Insert the circlip into the pulley.
 - c. Install the pulley on the pulley arm with the circlip facing the arm box, then insert the pulley bolt and a new lock nut. Install the grease nipple and lubricate with grease (XG-274).

UNCONTROLLED IF PRINTED




Figure 2 Jockey Pulley - Exploded View

12. Installation:

- a. Align the pulley arm bolt hole with the mounting hole, then, insert the adjusting bolt.
- b. Fit the fanbelts in the pulley grooves, then position the pulley arm to allow a deflection of 5-10 mm on the longest span of the belts, and tighten the lock nut securely.

SPECIFICATIONS

Table 1 Belt Deflection

Fanbelt Deflection (12 Volt Alternator)	10-15 mm
Fanbelt Deflection (24 Volt Alternator)	5-10 mm
Drivebelt Deflection	7-12 mm

ELECTRICAL - GROUP 15

Cargo Area Lights

13. To remove a LED fitting (Figure 3):

- a. Isolate the lights from the battery by removing leads from battery.
- b. Remove the two bezel screws from the lighting bracket.
- c. Pull the fitting from the lighting bracket and pull cable through the fitting hole.
- d. At a suitable point, cut the cable to the defective light and remove cable from lighting bracket.




Figure 3 Cargo Area LED Fitting

- 14.** To refit a LED fitting:
- a.** Position the cable for the light through the hole in the lighting bracket.
 - b.** Join the new fitting to the existing cable by using the suitable size cable connectors.
 - c.** Position the new fitting into the lighting bracket and insert and tighten the two loctite coated screws on the bezel.
 - d.** Reconnect battery leads and check light for operation.

Cargo Area Lights Switch

- 15.** To remove a cargo area light switch (Figure 4):
- a.** Isolate the battery supply by removing leads from battery.
 - b.** Remove the switch plate from the cabinet side by removing the two screws and withdrawing.
 - c.** Tag and disconnect the wiring harness from the light switch.
 - d.** Remove the hexagonal nut securing the switch to the switch plate, then remove the switch.
- 16.** To refit a cargo area light switch:
- a.** Insert the replacement switch in the switch plate and secure with the nut.
 - b.** Connect the wiring harness to the light switch, observing the identification tags.
 - c.** Position the switch plate over the recess in the cabinet side, insert and tighten the two loctite coated screws.
 - d.** Reconnect the battery leads, turn on the switch and check that the lights operate.




Figure 4 Cargo Area Light Switch

Crash Action Override Switch

17. To remove the crash action override switch (Figure 5):
- Isolate the battery supply by removing leads from battery.
 - Remove the switch plate from the cabinet side by removing the two screws and withdrawing.
 - Tag and disconnect the wiring harness from the light switch.
 - Remove the hexagonal nut securing the switch to the switch plate, then remove the switch.




Figure 5 Crash Action Override Switch

18. To refit a crash action override switch:
- Insert the replacement switch in the switch plate and secure with the nut.
 - Connect the wiring harness to the light switch, observing the identification tags.
 - Position the switch plate over the recess in the cabinet side, insert and tighten the two loctite coated screws.
 - Reconnect the battery leads, turn on the switch and check that the lights operate.

Alternator (24 Volt)

19. Removal:
- Disconnect the vehicle battery and the FFR system batteries.
 - Cut the lock wire securing the cannon plug to the alternator, then remove the plug.
 - Slacken the adjusting bolt on the jockey pulley arm (Figure 2), then rotate the pulley away from the fanbelts. Detach the two belts from the alternator pulley.

WARNING

The alternator is heavy. Care must be taken on removal or personal injury may result.

- Support the alternator, then remove the two bolts that retain the alternator clamp rings to the mounting. Carefully remove the alternator from the vehicle. Discard the lockwashers.
- Remove the four bolts, nuts and washers that secure the clamp rings on the alternator, then remove the clamp rings. Discard the lockwashers.

NOTE

Repair procedures are detailed in the Electrical P 41 decade of EMEIs.

20. Installation:
- Fit the two clamp rings on the alternator and install the four bolts, nuts and washers, but do not tighten at this stage (Figure 6)

WARNING

The alternator is heavy. Care must be taken on removal or personal injury may result.

- Support the alternator and clamp rings beside the engine cylinder block, then insert the two bolts that secure the clamp rings to the mounting. Fit the two nuts and new lockwashers and tighten securely.
- Ensure that the alternator and crankshaft pulleys are aligned by using a suitable straight edge, then connect the cannon plug. Using new lockwashers, install the four bolts and nuts on the clamp rings and tighten the nuts securely.




Figure 6 Alternator - Installation

- Fit the two belts in the alternator pulley grooves and check that they are correctly fitted to the crankshaft and compressor pulleys.
- Fit the fanbelts in the pulley grooves, then position the pulley arm to allow a deflection of 5-10 mm on the longest span of the belts, and tighten the lock nut securely.
- Lock wire the cannon plug to the alternator, then connect the vehicle and FFR batteries.

Wiring Harness

21. General Precautions:

- a. Use suitable testing meters or circuit testers to trace or locate faults and check circuits. The practice of arcing wires to earth to determine if the wire is live, will destroy solid state components, and must not be used.
- b. After tracing electrical faults, and before carrying out any electrical repairs, disconnect the batteries, negative terminals first.
- c. Before carrying out any electrical arc welding on the vehicle, disconnect the batteries, radio and the alternator. Failure to disconnect the alternator will cause the transistors and diodes to fail as a result of current flow throughout the chassis when arc welding.
- d. When installing the batteries, ensure that the terminals are connected to the correct posts. Reversing battery polarity will cause serious damage.

22. Replacement:

- a. Disconnect the batteries, negative terminals first, then disconnect the positive terminals (Figure 7).

NOTE

All chassis electrical wiring in the vehicle is colour coded for identification and reference. If necessary, refer to the wiring diagram (EMEI Vehicle G 203), in conjunction with the relevant illustration, when replacing a wiring harness. A module wiring diagram is located at the rear of this EMEI.

- b. Determine which harness is to be replaced and ensure that the replacement harness is of the correct capacity and that the wires are correctly colour coded. Using the old harness and tags as a guide, connect the wires to the appropriate terminals.
- c. Connect the batteries, the positive terminal first, then connect the negative terminal.
- d. Test the function of the components associated with the wiring harness that has been replaced to ensure correct function.

Batteries (24 Volt Installation)

23. Replacement:

- a. Switch off the master switch on the power distribution box.
- b. Remove the security clip and pin from the battery carrier, then slide the batteries and carrier clear of the vehicle body until the small bridging cable is exposed.



When removing the bridging cable, extreme care must be taken to prevent the cable ends shorting out on the vehicle body.

- c. Disconnect the bridging cable from both the positive and negative terminals on the batteries. Remove the cable.
- d. Disconnect the remaining cables from the batteries.
- e. Remove the nuts and washers securing the battery retaining bracket and remove the bracket.
- f. Lift the batteries out of the battery carrier.
- g. Install the batteries in the battery carrier and secure with the retaining bracket.
- h. Connect the battery cables as shown in Figure 7, and stow the battery carrier. Secure the carrier with the security clip and pin.
- i. Switch on the master switch.




Figure 7 Batteries - Installation

BODY - GROUP 17

Missile Stowage Desiccant Replacement

- 24. To change desiccant containers:
 - a. Open relevant missile stowage door.
 - b. Remove existing desiccant containers from stowage (Figure 8).




Figure 8 Missile Stowage Desiccant Position

- c. Place new desiccant containers into stowage.
 - d. Close missile stowage door.

Missile Stowage Thermohydrograph Replacement

- 25. To remove a thermohydrograph:
 - a. Open relevant missile drivers side stowage door.
 - b. Remove bunji strap securing the thermohydrograph in its holder (Figure 9).

UNCONTROLLED IF PRINTED

- c. Push the thermohydrograph from the bottom (through bracket) to remove it from the mounting case fitted in the holder.
26. To refit a Thermohydrograph:
- a. Place the thermohydrograph into the mounting case fitted in the holder ensuring that the display can be read from the outside of the door.
 - b. Position the bunji strap over the thermohydrograph and secure.
 - c. Close missile stowage door.




Figure 9 Thermohydrograph Replacement

UNCONTROLLED IF PRINTED

END

Distribution List: **VEH G 21.2 – Code 2** (Maint Level)
(Sponsor: LV SPO, Lt B Veh Section)
(DMO Job No AMP063.69)