RESTRICTED

TRUCK, TANK WATER, HEAVY, MC3, (MACK) SPARE WHEEL CARRIER - CROSS TUBE RETENTION COLLARS

## MODIFICATION INSTRUCTION

Issue of this instruction is authorized by CONMEA

## Introduction

1. This instruction details the work necessary to provide a more positive method of securing the spare wheel carrier cross tube retention collars.

Note:

 NSN and Designation used in this instruction were current at the date of issue. If twelve months or more have expired since issue, the NSN should be checked for supersession.

## General

Ζ

2. Estimated Manhours to Perform. 0.2 (initial planning only).

3. Priority. Group 2.

4. <u>Modification to be Applied to.</u> All subject vehicles that have not had the cross tube retention collars modified.

 $\Box$ . Item Affected. Spare wheel carrier cross tube.

6. Action Required. By RAEME units authorized to carry out unit, field and base repairs in accordance with WKSP A 850.


TABLE 1 - STORES REQUIRED (To be demanded through normal supply channels)

Item	NSN	Designation	Qty per Equip
	5306-66-019-3755	BOLT, MACHINE, UNF, 2A, SAE, GRADE 5 STEEL, HEX HD, ZINC COATED, 1/4 INCH BY 1 INCH LONG	2
2.	5310-66-010-7828	NUT, SELF-LOCKING, HEXAGON, UNF, 2B, "P" STEEL, TYPE P, ZINC COATED, 1/4 INCH, WITH NYLON INSERT	2

Detail

- 7. To carry out the modification refer to Fig 1 and proceed as follows:
  - a. Remove the two lock screws from each retention collar.
  - b. Ensure that the spare wheel carrier cross tube is correctly positioned to allow the wheel to enter its cradle without fouling.
  - c. Position the retention collars to allow a 1 mm clearance between the collars and the cross tube support bracket. Lock each collar in position using one of the original lockscrews.
  - d. Drill a 7 mm hole through both the collar and the cross tube using the other lock screw hole as a pilot.

- e. Drill the remaining collar in the same manner.
- f. Lock both collars firmly in position using items 1 and 2 from Table 1.



END